

NOTES:

- 101> RECOMMENDED CLEARANCE FOR MACHINE ACCESS AND MAINTENANCE IS 1000 MM (39"). ACTUAL DISTANCE TO BE DETERMINED BY LOCAL CODES/REGULATIONS.
- 102> SEE PUMP PRE-INSTALL DRAWING FOR SIZE AND REQUIREMENTS.
- 103 UTILITY DROPS FOR AIR, WATER, AND POWER LOCATIONS ARE
 APPROXIMATED. IF EQUIPPED WITH LIGHT CURTAINS, DROPS MUST NOT INTERFERE WITH CURTAIN SIGNAL.
- 104 LOCATION SHOWN FOR REFERENCE. ABT CAN BE LOCATED WITHIN

 CABLE AND HOSE LIMITS. EXTENSION KITS ARE AVAILABLE FOR ALTERNATE


 LOCATIONS IF REQUIRED. SEE ABT PRE-INSTALL DRAWING FOR SIZE AND REQUIREMENTS.
- [106] RECOMMENDED CLEARANCE ON ALL SIDES OF THE ABT IS 1000 MM (39").
- 107. FOUNDATION PAD TO BE A MINIMUM OF 610 MM (24") LARGER THAN CATCHER AND MAIN SYSTEM BASES. PAD TO BE MONOLITHIC SLAB, FREE OF CONSTRUCTION JOINTS OR CRACKS. OVERALL FLATNESS TO BE +/- 13 MM (1/2").
- 108 UTILITY DROP FOR MACHINE POWER. REQUIRED ONLY WHEN USING A CUSTOMER-SUPPLIED HIGH-PRESSURE PUMP.

DIMENSIONS ARE IN MILLIMETERS. DIMENSIONS IN BRACKETS ARE IN INCHES.

<u>LEGEND</u>

 \oplus utility drop

- MACHINE HOME



063462

1 OF 2

BASE PART

SCALE

REVISION

UNCONTROLLED COPY. USER IS RESPONSIBLE FOR VERIFYING THE CURRENT REVISION LEVEL.

