

COMPLETE METALWORKING SOLUTIONS

(800) 991-4225 www.ahbinc.com ISO Certified customerservice@ahbinc.com

Hello,

Cleaning and maintaining the units is fairly easy.

- 1. Turn the unit off and disconnect from power source
- 2. Remove all cells-prefilter and electrostatic cells
- 3. These can be washed in several ways
 - a. Dip tank- with degreaser. Mistbuster recommends their product "Mistbuster Total Oil Cleaner" we can quote if you like. Simple Green, Super Clean or any other HD degrease also will work well
 - b. Parts washer
- 4. After washing each stage needs to dry completely-I would suggest 24 hours
- 5. Inspect thin wires and replace if broken
- 6. Wipe out cabinet
- 7. Reinstall cells
- 8. Power up

I have attached a video for your review. It has a lot of information.

Call we if you would need any more help.



MistBuster® Training Video

(800) 991-4225 www.ahbinc.com • customerservice@ahbinc.com ISO Certified